Electrolux Sensitive Plus 8kg, Time Manager function, LCD control panel, 4.5 star water rating, 4 star energy rating

Product Details

FEATURES

Time manager wash option	Cycle start/pause button	End of cycle/fault warning chime	Synthetics, delicates, woollens, silk and hand wash
Special programs for easy iron	Special programs for silk	Special programs quick 14	Special programs bedding
Rinse, drain & spin programs	Pre-wash option	Extra rinse wash option	Delay start wash option
3-chamber detergent dispenser draw	Cottons wash program	Eco wash program	

BENEFITS

Vapour action™ technology
The new Vapour Action™ helps reduce allergens and germs, provides more efficient washing, softer laundry, whiter whites and reduces garments being attached to the drum

Lessen exposure to irritants that cause skin allergies
Sensitive plus program uses a unique rinsing cycles that effectively removes almost all the foreign residue from your clothes

Control the wash time
Time Manager functionality puts you in control of the wash time – to the minute – depending on how dirty the load is and how much time you can spare

4.5 WELS# stars
A minimum 4.5 WELS# star rating ensures efficient use of water without reducing the wash quality

Specifications

PRODUCT PROFILE

Washing Machine Type	Front load washing machine
Domestic warranty details (yrs)	2
Front Loader Type	Front Loader
Capacity (Kg)	8
Frontloader Wash system	jetsystem

DIMENSIONS

PRODUCT

Total height (mm)	850
Total width (mm)	600
Total depth (mm)	650
Depth with hoses (mm)	660

ENERGY FOR WASHING

Water Efficiency Star Rating	4.5
Water Consumption (litres)	68
Energy Efficiency Star Rating	4
Energy Consumption Warm (KWhr/yr)	326
Energy Consumption Cold Water (kWhr/yr)	168

WASH PROGRAMS

Number of Programs	11
Frontloader Wash programs	rinse,drain,spin,Delicate,woollens,hand wash,synthetics,easy iron,sensitive plus,silk,delicates plus,quick 14,Bedding,rinse,Drain & Spin,night cycle
Wash options	Prewash
Dispenser	detergent dispenser,fabric conditioner dispenser,pre-wash dispenser

CONTROLS

Type of controls	rotary,push button
Control panel colour	white
Functions available	wash cycle progress indicator,door lock indicator,time remaining,fault diagnostic display,delay start,prewash,extra rinse,load sensing,time manager
Type of display	LCD

BOWL

Drum material	stainless steel
Easy access angled drum	No

DOOR

Reversible	No
door lock	Yes

CABINET

Cabinet Colour	white
Cabinet material	painted galvanized steel

TECHNICAL

Water pressure requirements min	50
Water pressure requirements max	800
Water supply	cold
Motor type	inverter

TECHNICAL

Maximum spin speed	1200
Variable spin speed	Yes

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640
fax: 1800 350 067
email: customercare@electrolux.com.au
web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230
fax: 09 573 2221
email: customercare@electrolux.co.nz
web: www.electrolux.co.nz