

Only one appliance can be installed on an Electrolux PDSTP10K — the stand can support only one washer, or one dryer for Electrolux Washers and Dryers



Product Details

FEATURES

Foldable laundry basket

Easy open basket

Extra storage space

BENEFITS

Foldable Laundry Basket

Designed to fit perfectly within the Pedestal when not in use. The Foldable Laundry Basket conveniently opens and expands for easy unload of your washer or dryer

Extra Storage

Provides additional space to perfectly store your laundry supplies

Ergonomic Solution

The PDSTP10 Pedestal lifts either the washer or the dryer off the floor which means less distance to bend when unload clothes

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs) 2

Product Relates to Microwave

DIMENSIONS

Total height (mm) 315

Total width (mm) 600

Total depth (mm) 548

SPECIFICATIONS

Material Painted Metal

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz