












Fridge Water Filter Guide

Choose the right filter for your fridge using the table below

For pure great tasting water, replace your water filter at least every 6 months

Model Series	Model Image	Compatible Water Filter/s	Visit our Shop
EBE5167		ACC139 / 1450970	Buy Now
EBE5367		ULX220 / 807946705	Buy Now
EHE5167		ACC139 / 1450970	Buy Now

For pure great tasting water, replace your water filter at least every 6 months

Model Series	Model Image	Compatible Water Filter/s	Visit our Shop
EHE5267		ULX220 / 807946705	Buy Now
EHE6899		ULX220 / 807946705 ACC208	Buy Now Buy Now
ERE5047		ULX220 / 807946708	Buy Now
ESE6077		ACC139 / 1450970	Buy Now
ESE6078		ACC139 / 1450970	Buy Now
ESE6977		ACC139 / 1450970	Buy Now